

Example: Right lanes – one bare wheel path Left lanes – mostly bare pavement



Examples: Near normal prudent winter weather driving conditions



This is a city street showing both driving lanes as plowed where patches of pavement are visible. This road meets the definition of passable.



This is a city street showing both driving lanes as plowed yet no pavement visible. This road meets the definition of passable.



This is a second priority city street showing both driving lanes as plowed yet limited pavement visible. This road meets the definition of passable. Lack of bare wheel path most likely to occur during times of extreme cold (10 degrees or less).