


c:\sawdara\work\sidewalk\vandiver-1 b to parker\vandiver_sdw_topo & aerial.dwg

No.	Date	By	Revision

**VANDIVER DRIVE SIDEWALK
OAKLAND GRAVEL TO PARKER
PROPOSED SIDEWALK LAYOUT 1**

Mission
Provide safe, sustainable
infrastructure that promotes
positive communities.

701 East Broadway
P.O. Box 6015
Columbia, MO 65205
(313) 875-2489



Shane Steven Creach
Registered Professional
Engineer
PE-2007011061

File No.
Scale: 1"=40'
Date: 07/18/2023
Des. AAA
Dwn.
Chk.




No.	Date	By	Revision

VANDIVER DRIVE SIDEWALK
 OAKLAND GRAVEL TO PARKER
 PROPOSED SIDEWALK LAYOUT 2

Mission
 Provide safe, sustainable infrastructure that promotes positive communities.


701 East Broadway
 P.O. Box 6015
 Columbia, MO 65205
 (314) 875-2489



Shane Steven Creech
 Registered Professional Engineer
 PE-2007011061

File No.
 Scale: 1"=40'
 Date: 07/18/2023
 Des. AAA.
 Dwn.
 Chk.

C:\working\shane\columbia\projects\2023\23-0013\23-0013-01\23-0013-01.dwg



- NOTE:
1. SIDEWALK SHALL BE 4" THICK MoDOT PAVEMENT CONCRETE.
 2. INSTALL 1/2" EXPANSION JOINTS AT INTERSECTIONS, RAMPS, STRUCTURES, DRIVEWAY APPROACHES, OR EVERY 100'.
 3. INSTALL TRANSVERSE SAW JOINTS AT SPACING EQUAL TO SIDEWALK WIDTH.
 4. STANDARD SIDEWALK PLACEMENT IS 12" FROM RIGHT OF WAY LINE.
 5. NO STEEL TO BE PLACED THROUGH EXPANSION JOINT.
 6. SIDEWALK CROSS SLOPE SHALL NOT EXCEED 2.00%.
 7. WWR OR REBAR SHALL BE ACCURATELY PLACED AND FIRMLY HELD IN PLACE DURING CONCRETE PLACEMENT BY APPROVED METHODS, SEE SECTION 238.9.

SIDEWALK WITH GRASS PARKWAY
 (NOT TO SCALE)